
# BAR HEIGHT CHAIR & COUNTER HEIGHT CHAIR INSTRUCTIONS

Sunrise chair back different than shown. Crescent chair back different than shown. Counter Height Chairs are 5" shorter than Bar Height Chairs.




# **ASSEMBLY**

**STEP 1.** Cut zip ties to remove spreader bar arms from leg assembly. Use (4) 2" screws to attach left and right spreader bar arms to foot rest and spreader bar.



### HARDWARE PACK



# **CHAIR PARTS**


- CHAIR BACK
- CHAIR SEAT
- LEFT ARM/LEFT LEG ASSEMBLY
- RIGHT ARM/RIGHT LEG ASSEMBLY
- SPREADER BAR
- FOOT REST
- LEFT SPREADER BAR ARM
- RIGHT SPREADER BAR ARM


### **SUGGESTED TOOLS**


- RUBBER MALLET
- KNIFE OR SCISSORS
- PHILLIPS HEAD SCREWDRIVER
- DRILL


STEP 2. Use (14) 2" barrel bolts, (14) barrel nuts and (2) pegs to attach right & left arm/ leg assembly to chair seat and foot rest. Keep all barrel bolts loose until Step 4.











Congratulations on purchasing this Durawood Sunrise/Essentials/Crescent Bar Height Dining Chair/Counter Height Chair. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

RESIDENTIAL WARRANTY - This quality product includes a LIMITED LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, or chipping should ever occur, The Hammock Source will supply replacement parts or replace the furniture, at no charge to you. This does not include negligence, improper use, animal damage or damage caused by natural disasters. When using around fire, keep furniture at a minimum distance of 30 inches from the heat source. Prevent prolonged exposure to chlorinated water. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call tollfree at 252-758-0641.

CONTRACTOR WARRANTY - CONTRACTORS receive a LIMITED 7-YEAR WARRANTY. Follow the same steps outlined above.

