



**Step 4**



# Double Cushioned Swing INSTRUCTIONS




**WARRANTY & RETURNS**

**Pawleys Island Hammocks** products are guaranteed to be free of defects in both workmanship and materials for up to one year from the date of purchase. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty, nor is damage caused by animals, negligence, normal wear, mildew, or improper care, including storage, maintenance, and assembly. If you are not satisfied with an item, return it unused in its original packaging for a complete refund or exchange. You can return it to our store or to our warehouse, **Pawleys Island Hammocks, 305 Industrial Blvd, Greenville, NC 27834**. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Pawleys Island Hammocks customer service; call (252) 758-0641.

Installation methods not included in these instructions are not recommended. Inspect wooden beams used for installations prior to assembly and before each use.

**Maintenance** - Periodically check bolts after assembly and re-tighten when necessary.


**SWING PARTS**




**HARDWARE PACK**




(10) Lock Nuts  
(F)




(14) Washers  
(G)




(2) Tree Hooks  
(H)



(2) 1 1/4" Bolt  
(I)




(2) 2 1/2" Bolt  
(J)




(2) 3" Bolt  
(K)

**Step 1**

Repeat all steps on both sides



**Step 2**



**Step 3**

