CHAISE LOUNGE **INSTRUCTIONS**

ASSEMBLY

STEP 1. Use (6) 2” torx screws to attach spreader bars to front, center and wheeled back legs.



HARDWARE PACK



(12) 3” BARREL BOLTS

(6) 2” TORX SCREWS

(12) LOCK NUTS

(12) WASHERS

(1) ALLEN WRENCH

(1) TORX HEAD BIT

CHAIR PARTS

- SEAT BACK
- LOUNGE BASE
- (2) FRONT LEGS
- (2) CENTER LEGS
- (2) WHEELED BACK LEGS
- (2) ARM ASSEMBLIES
- (3) SPREADER BARS

SUGGESTED TOOLS

- RUBBER MALLET
- SOCKET WRENCH
- 7/16” x 1/4” DEEP SOCKET
- DRILL

ASSEMBLY

STEP 2. Use (6) 3” bolts, (6) washers and (6) lock nuts to attach lounge base to front, center and wheeled back legs.



STEP 3. Use (2) 3” bolts, (2) washers and (2) lock nuts to attach seat back to lounge base.



STEP 4. Use (4) 3” bolts, (4) washers and (4) lock nuts to attach arm assemblies to lounge base.



Congratulations on purchasing this Durawood Chaise Lounge. QUESTIONS REGARDING THIS PRODUCT? Call our customer service team, 252-758-0641.

RESIDENTIAL WARRANTY - This quality product includes a LIMITED LIFETIME WARRANTY for RESIDENTIAL CUSTOMERS. In the unlikely event any splintering, rotting, cracking, peeling, or chipping should ever occur, The Hammock Source will supply replacement parts or replace the furniture, at no charge to you. This does not include negligence, improper use, animal damage or damage caused by natural disasters. When using around fire, keep furniture at a minimum distance of 30 inches from the heat source. Prevent prolonged exposure to chlorinated water. Note that an original sales receipt must accompany any returned product, along with a Return Authorization Number from Hammock Source customer service; call at 252-758-0641.

CONTRACTOR WARRANTY - CONTRACTORS receive a LIMITED 7-YEAR WARRANTY. Follow the same steps outlined above.

MAINTENANCE - Thoroughly inspect product before each use. Periodically check bolts after assembly and re-tighten when necessary.